


## How to Retune/Rescan Your Top Up TV Digital Recorder

This applies to all Top Up TV Digital TV Recorders model types

Follow these simple instructions to Retune/Rescan your Top Up TV Digital Recorder to ensure that you have all the channels available to you after **National Retune Day** on the 30<sup>th</sup> September, 2009. Please note that some channels will be reordered on the Guide (different number) after the retune which is in line with the UK digital project.




### Using the DTR remote control

- Press **Menu** button

Then

- Press **Set-Up** (4)



### Using the DTR remote control

- Press **Scan for Channels** (1)



### Using the DTR remote control

- Press **Green** button to begin scan

After approx 8 minutes '**scan complete**' will be shown

- Press **Live TV** button to resume viewing